

If you need assistance please contact us at support@motote.com or in the US call 888-333-4621
In Australia patrick@nicerack.com.au



The Easiest way to haul your Bike.



INSTRUCTIONS LED TAIL LIGHT KIT



In the Box:
Light kit assembly
4 mounting screws
Black nylon ties

Australian version has 7-pin plug and amber turn signals



You will need:
Flathead and philips head screwdrivers
Scissors or knife to cut nylon ties
If you purchased your MotoTote before April 2014 you will also need a drill with a 5/32" or 4mm bit



1

SEPARATE FROM BEZEL

Separate light from bezel (base) with a flat head screwdriver as shown leaving the cable running through bezel.



2

ATTACH BEZELS

IDENTIFY left/right light by labels on back. Attach bezel to MTX Platform tube with screws provided and pre-punched holes.


NOTE: If you bought your MotoTote before April 2014 you will need to drill two more holes in the MTX Platform tube (one for each light). First drive screw in outer hole as shown in step 2 above, then use bezel as guide to drill the additional inboard hole.



3

PRESS INTO BEZEL

Press light into bezel with palm of hand as shown until it "snaps" into place.



4

SECURE CABLES

Run the cables along the underside of the MotoTote toward center then forward toward vehicle. Secure with the nylon ties.



5

CONNECT AND CHECK

Plug into vehicle connector and check for proper operation as described at right.



Australian connector

Check for proper operation of brake, turn signal, and tail lights. Apply brakes and use turn signals with the headlights on. Repeat with the headlights off (tail lights will be off but brake and turn signals should work).