

MOTO-TOTE[®]

Motorcycle carriers

Instructions Light Kit

1

Items in box

Your box should include:

- Light kit assembly
- Wire routing clips with adhesive backing



2

Tools

You will need these tools:

- Pliers or small wrench
- Phillips screwdriver



3

Assembly

- **Check left/right** by connecting to plug on vehicle and using turn signals to verify correct left/right placement. If your vehicle does not have a plug or has a different kind of plug, see your local hitch dealer.
- **Attach lights** to carrier by putting the screws through the pre-punched holes on the sides of the carrier track as shown here. Do not over-tighten.
- **Route wiring** along the underside of the carrier toward the center, then forward under the square tube toward the vehicle. Use the wire clips to attach the wiring to the carrier. If the carrier is not new, clean the carrier at the attachment points with solvent (paint thinner or fingernail polish remover) before attaching, for proper adhesion.



MOTO-TOTE is a registered trademark of D&D Design, Inc.
Patent #D393241

by *D&D Design, Inc.*

For more information, call (888) 333-4621 or visit MOTOTOTE.com